

## **Wicker Basket – Specification**

### **Application**

- The basket is designed for household or garden use.
- Ideal as a practical container for carrying lightweight items, organizing spaces, or decorating interiors.
- Perfect as a base for gift arrangements.

### **Safe Usage**

- The wicker basket may have sharp ends or protruding wicker strands, especially along edges or handles. Use carefully to avoid injuries.
- The basket is not intended for carrying heavy items. Overloading may deform or break the wicker.
- Wicker is not suited for prolonged exposure to water, which can weaken it and cause mold. Store the basket in a dry place.

### **Maintenance**

- The basket can be gently wiped with a damp cloth. For heavier dirt, wash the wicker with water and a mild detergent, then dry thoroughly in the sun.
- To extend the basket's durability, apply special wicker impregnants or clear lacquer. This protects it from moisture and dirt.
- Store the basket in a dry, well-ventilated area to prevent mold and weakening of the structure.

### **Warnings**

- This product is not intended for use near open flames or for carrying flammable materials.