

## **Wicker Fence – Specification**

### **Application**

- The fence is designed for outdoor use as both a decorative and practical element in gardens, terraces, or allotments.
- It is used to define spaces in gardens, such as flower beds or green zones.

### **Safe Usage**

- The fence is assembled using staples to secure the wicker branches. Some staples may slightly protrude, posing a risk of injury. Before installation, inspect the edges of the fence and trim any protruding parts if necessary.
- Wooden stakes are sharpened to facilitate driving into the ground. Exercise caution during their placement.
- Ensure the fence is firmly anchored in the ground to guarantee stability. Improper installation may cause the fence to topple, especially during strong winds.

### **Maintenance**

- Wicker is a natural material and susceptible to weather conditions. To extend its durability, it is recommended to protect its surface with a wicker preservative or clear lacquer.
- For cleaning, simply wipe the fence with a damp cloth. Avoid using strong detergents that may damage the wicker.
- Although the product is intended for outdoor use, prolonged exposure to moisture (e.g., heavy rain) may weaken the wicker. Position the fence in an area with good air circulation.
- At the beginning of each season, check the condition of the fence and stakes to identify and address any damage.

### **Warnings**

- The product is not designed to support weight or climbing. Doing so may damage the fence and pose a safety hazard to the user.
- Exercise caution during installation – do not direct the sharp ends of stakes toward yourself or others.